

## ZUIKO DIGITAL ED 300mm 1:2.8

- Pro Lens Fixed Focal Length
  - Top class telephoto lens
- 1:2.8 maximum aperture - strong light gathering power
- Dust & splashproof



### Our top class telephoto lens

This 300mm lens is ideal for sports and nature photography. It is an extremely bright but compact lens, making it easy to handle. Even so, it has the equivalent performance of a 600mm 1:2.8 lens on a 35mm film camera, despite being approximately half the size. The three high-performance ED elements deliver superb sharpness.

### Specifications

#### Focal Length

Focal length	300mm
Focal length (equiv. 35mm)	600mm

#### Lens Construction

Lens configuration	13 elements / 11 groups
ED lens elements	3
Lens mechanism	Inner focus with floating mechanism
Angle of view	4.2°
Closest focusing distance	2.4m
Maximum image magnification	0.15x (Four Thirds) / 0.3x (35mm format)

#### Aperture

Number of aperture blades	9
Maximum aperture	1:2.8
Minimum aperture	1:22

#### Dimensions

Filter diameter	43mm
Length	281mm
Diameter	129mm
Weight	3290g (with tripod adapter)

#### Compatibility

Compatible to Extension Tube EX-25	Yes; maximum image magnification: 0.25x
Compatible to Tele Converter EC-20	Yes
Compatible to Tele Converter EC-14	Yes

#### Application

Recommended Uses	Low light Nature Sports
------------------	-------------------------------