

M.Zuiko Digital ED 12mm F2 Black

- Snapshot focus mechanism
- High-specification design with metal housing
- Superior image quality performance
- High-speed AF with MSC technology
- Versatile wide-angle fixed focal lens
- Ideal for capturing quality landscapes
- New advanced multi coating



For razor-sharp images at any time

Packed in a high-grade, sleek metal body, this compact lens is ideal for taking enviable wide-angle photos in low-light conditions. It not only provides a snapshot mechanism, activated simply by pulling the focusing ring back, with distance and depth of field indicators – it also delivers sophisticated image quality paired with a maximum aperture of F2. The ZERO (Zuiko Extra-low Reflection Optical) coating halves distracting and unwanted reflections compared to conventional coating.

All M.Zuiko lenses are compatible with the entire range of Olympus PEN and OM-D cameras as well as other MFT cameras.

Specifications

Focal Length

Focal length	12mm
Focal length (equiv. 35mm)	24mm

Lens Construction

Lens configuration	11 elements / 8 groups
DSA lens elements	1
Aspherical glass elements	1
ED lens elements	1
Super HR elements	1
Lens mechanism	Inner focus with screw drive mechanism
Angle of view	84°
Closest focusing distance	0.2m
Maximum image magnification	0.08x (Micro Four Thirds) / 0.16x (35mm format)

Aperture

Number of aperture blades	7 Circular aperture diaphragm for natural background blurring
Maximum aperture	F2
Minimum aperture	F22

Dimensions / Weight

Filter diameter	46mm
Length	43mm
Diameter	56mm
Weight	130g

Application

Recommended Uses	Architecture Low light Nature Travel Landscape
------------------	--

Compatibility

Compatible to Tele Converter MC-14	No
Compatible to Tele Converter MC-20	No