

M.Zuiko Digital ED 14-150mm F4-5.6 II

- High-power 10.7x zoom
- Optimised for movie shooting with low focusing noise
- Circular aperture diaphragm
- Dust, splash & freezeproof
- Extremely fast high-speed contrast AF
- Ultra compact with a length of only 83mm
- ZERO (Zuiko Extra-low Reflection Optical) coating for low-reflectivity



Your all-in-one zoom

This M.Zuiko Digital ED 14–150mm F4–5.6 II (28–300mm*) lens from Olympus is a high-powered zoom for all your needs: from wide angle to telephoto. Packed in a compact, lightweight design, it eliminates the need to constantly change lenses – leaving you to quickly catch the perfect photo opportunity. No matter where you are going, you are prepared for any kind of photographic situation, as this lens features a robust weatherproof construction. Also featuring MSC, it allows an exceptionally fast and quiet AF with smooth operation.

*35mm equivalent

All M.Zuiko lenses are compatible with the entire range of Olympus PEN and OM-D cameras as well as other MFT cameras.

Specifications

Focal Length

Focal length	14 - 150mm
Focal length (equiv. 35mm)	28 - 300mm

Lens Construction

Lens configuration	15 elements / 11 groups
Aspherical glass elements	3 (1 is ED glass)
Lens mechanism	Inner focus
ED lens elements	2
Angle of view	75 - 8.2°
Closest focusing distance	0.5m
Maximum image magnification	0.22x (Micro Four Thirds) / 0.44x (35mm format)

Aperture

Number of aperture blades	7 Circular aperture diaphragm for natural background blurring
Maximum aperture	F4 (wide) / F5.6 (tele)
Minimum aperture	F22

Dimensions / Weight

Filter diameter	58mm
Length	83mm
Diameter	63.5mm
Weight	285g

Application

Recommended Uses	Portrait Architecture Nature Travel Landscape Allround
------------------	---

Pro Features

Dust, splash & freezeproof	Available
----------------------------	-----------

Compatibility

Compatible to Tele Converter MC-14	No
Compatible to Tele Converter MC-20	No